



Compaq Presario V2414NR Battery Replacement

This guide shows how to replace the battery in your Compaq laptop.

Written By: Ryan Schmidt



INTRODUCTION

Without a working battery, a laptop becomes anchored to a wall outlet. That's not very mobile! In this guide, you will learn how to remove and replace the battery.

Step 1 — Battery



- Shutdown the computer.
- Remove all external devices.
- Unplug the power, and any other cords, from the laptop.
- Turn the laptop upside down, with the front towards you.

Step 2



- Slide the battery release latch to the left until the battery pops up.
 - Lift the front edge of the battery pack and swing it back to remove it.
- ☑ When reassembling, first align the back of the battery with the chassis, then press the front downwards until it latches.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 08:54:37 PM.